

Product Information Sheet

Drive Over Floor Bunding

ENVIRONMENTALLY FRIENDLY & COST EFFECTIVE

Designed for applications where storage and containment of liquids is required in an area where truck or forklift access is also required. This product is an inexpensive alternative to masonry bunding.

Contains liquid spills within existing workshops without the need for major construction.

Constructed with 100% memory foam with a HF welded heavy duty PVC cover, this bund is designed to withstand moderate volumes of traffic in a busy workplace.

Also available with a sacrificial layer which can be replaced when worn.

The bund is secured to the floor by adhesive (Sikaflex) and for heavy duty applications is further secured with flat steel and dynabolts (Flat steel, dynabolts and Sikaflex not included).

Features:

- Ideal for workshops and forecourt areas.
- Suits heavy duty applications
- Minimal impact on loaded forklifts
- Eliminates the need for expensive masonry wall bunding
- High visibility yellow.

Sizing:

- 65mm height
- 135mm width
- 5m length

PART #	DESCRIPTION	SIZE
19820017	Drive Over Bunding	65mm x 135mm x 5m



Installation Instructions:

1. Thoroughly clean floor surface that bunding is to be fixed to.
2. Glue bunding to floor using Sikaflex.
3. Fix flat steel bar (25mm x 3mm) on flaps of bunding and dyna bolt to floor every 500mm.

Other related spill control products and absorbent materials can be found on our website.

www.newpig.com.au

Matthews
SAFETY PRODUCTS
1 800 HOT HOG (468 464)