

# Dangerous Goods and Safety Storage Cabinets



## Flammable Storage Cabinets



Flammable Safety Storage Cabinets provide a safe, close-by, secure and time-saving method for storing all types of dangerous chemicals and help you to maintain good housekeeping practices.

The cabinets supplied by Matthews are fire tested to comply with the FM rating, something no other cabinet sold in Australia can claim, they also not only comply, but exceed Australian Standard AS 1940. They help companies by providing product near to the workplace thus avoiding the time consuming and often risky practice of collecting classified items from an outside storage facility.

- Fully welded construction - 1.2mm steel - Double wall - 40mm thermal barrier
- Superior electrostatic high gloss powder coat paint finish / Dual vents with built in flash arresters
- Close fitting, sequential self closing and latching doors / 3 point locking mechanisms
- Leakproof fully welded 150mm deep containment sump / Shelves with built in troughs to contain spills
- Adjustable shelf height increments to maximise space storage
- Adjustable levelling feet to prevent doors binding Fire tested, FM Approved exceeds AS1940 compliance

### SAFETY DRUM STORAGE



#### AU25701

207 Litre Vertical Drum  
2 Door with rollers



#### AU25662

207 Litre Horizontal Drum  
2 Door



### INDUSTRIAL SAFETY CAN STORAGE

#### AU25452

3 Shelves / Capacity 250 Litre  
9 x 20 Litre Drums



#### AU25302

2 Shelves / Capacity 160 Litre  
6 x 20 Litre Drums



### COMPACT SAFETY CAN STORAGE

#### AU25714

2 Shelves / Capacity 30 Litre



### Under Bench Storage

#### AU25748

2 Shelves / Capacity 100 Litre

## Flammable Storage Cabinets

## Approval

## Weight Kg

## H x W x D mm

### Drum Cabinets...Yellow Powder Paint Finish

AU25662	207 Litre Horizontal Drum - 2 Door		168	1385 x 765 x 1225
AU25701	207 Litre Vertical Drum 2 Door With Rollers	FM	180	1760 x 870 x 870
AU25701W	207 Litre Vertical Drum 2 Door for Waste Products	FM	180	1760 x 870 x 870

### Storage Cabinets...Yellow Powder Paint Finish

AU25302	160 Litre, 2 Shelves, 2 Door, 6 x 20 Litre Drums	FM	105	1230 x 1100 x 465
AU25452	250 Litre, 3 Shelves, 2 Door, 9 x 20 Litre Drums	FM	142	1760 x 1100 x 465
AU25602	350 Litre, 3 Shelves, 2 Door, 15 x 20 Litre Drums	FM	180	1760 x 870 x 870

### Tray Top or Under Bench Cabinet...Yellow Powder Paint Finish

AU25748	100 Litre, 2 Shelves, 2 Doors	FM	85	800 x 920 x 565
---------	-------------------------------	----	----	-----------------

### Compac Storage Cabinet...Yellow Powder Paint Finish

AU25712	60 Litre, 2 Shelves, 1 Door	FM	59	1005 x 595 x 465
AU25714	30 Litre, 2 Shelves, 1 Door	FM	56	800 x 595 x 465

Other related spill control products and absorbent materials can be found on our website.

[www.newpig.com.au](http://www.newpig.com.au)

**Matthews**  
SAFETY PRODUCTS

1800 HOT HOG (468 464)

# Corrosive Storage Cabinets



Corrosive Substance Storage Cabinets have a Polyethylene tray on each shelf to collect any accidental spillages.

Designed to withstand fire these cabinets provide a safe environment to store most corrosive chemicals.

If you need to store chemicals such as Phenol, Nitric Acid, Sulphuric Acid or other substances with highly corrosive vapours, we suggest you look at the all Polyethylene Cabinets.

## Pesticide Storage Cabinets



**AU25712B**  
2 Shelves / 3 Polyethylene Trays  
60 Litres



**Polyethylene Storage Cabinet**  
**24160**  
2 Shelves / 30 Litres



**AU25302B**  
2 Shelves / 3 Polyethylene Trays  
160 Litres / 6 x 20 Litre Drums

### Corrosive Storage Cabinets Approval Weight Kg H x W x D mm

*These Cabinets are manufactured to comply with AS 3780 for the safe storage of Corrosive Substances.*

#### Blue Powder Paint Finish

AU25452B	250 Litre, 3 Shelves, 2 Door, 9 x 20 Litre Drums	FM	142	1760 x 1100 x 465
AU25302B	160 Litre, 2 Shelves, 2 Door, 6 x 20 Litre Drums	FM	105	1230 x 1100 x 465
AU25748B	100 Litre, 2 Shelves, 2 Doors	FM	85	800 x 920 x 565
AU25712B	60 Litre, 2 Shelves, 1 Door	FM	59	1005 x 595 x 465
AU25714B	30 Litre, 2 Shelves, 1 Door	FM	56	800 x 595 x 465

#### Blue Polyethylene Construction

24040	15 Litre, 1 Door		10	500 x 365 x 415
24160	30 Litre, 3 Shelves, 2 Door		42	890 x 920 x 565

### Organic Peroxide Storage Cabinets Approval Weight Kg H x W x D mm

*These Cabinets are designed to comply with AS 2714 and have a sump capacity equal to the total of the contents of the Cabinet. They are designed so that in the event of an explosion the doors will open outwards. For this reason the maximum capacity of a Cabinet is 100 kg or 100 L.*

#### Storage Cabinets...Yellow Powder Paint Finish

AU25452OP	100 Litre, 3 Shelves, 2 Doors	FM	142	1760 x 1100 x 465
AU25748OP	60 Litre, 2 Shelves, 2 Doors	FM	85	800 x 920 x 565
AU25712OP	50 Litre, 2 Shelves, 1 Door	FM	59	1005 x 595 x 465

### Pesticide Storage Cabinets Approval Weight Kg H x W x D mm

*These Cabinets are manufactured for the safe storage of Pesticides. A Safety Shower and Eye/Wash must be installed where packages are opened..*

#### Storage Cabinets...Green Powder Paint Finish

AU25602P	350 Litre, 3 Shelves, 2 Door, 15 x 20 Litre Drums	FM	180	1760 x 870 x 870
AU25452P	250 Litre, 3 Shelves, 2 Door, 9 x 20 Litre Drums	FM	142	1760 x 1100 x 465
AU25302P	160 Litre, 2 Shelves, 2 Door, 6 x 20 Litre Drums	FM	105	1230 x 1100 x 465

## Flammable Safety Storage Cans & Production Safety Equipment

Fire protective inplant storage of flammables. Heavy-duty with double-seamed construction. All models have built in flash arresters to eliminate the risk from flashback causing explosion.

#### SAFETY STORAGE CANS



**10301** 3.8 Litres  
**10501** 7.6 Litres  
**10801** 19 Litres  
**14140** Polyethylene 3.8 Litres

#### SAFETY DISPENSING CANS



**10821** 19 Litres  
**10807** Self Dispensing Can 19 Litres  
(3.8, 7.6 & 11 Litres) (3.8 & 11 Litres)

#### PLUNGER / BENCH / LIQUID DISPOSAL / OILY WASTE CANS



**10108** Plunger Pump Can 1 Litres (0.5, 2 & 4 Litres)  
**10295** Bench Can 1.9 Litres (0.5 to 11 Litres)  
**14722** Liquid Disposal Can 7.6 Litres (19 Litre)  
**09100** Oily Waste Can 23 Litres (23 to 80 Litre)

Other related spill control products and absorbent materials can be found on our website.

[www.newpig.com.au](http://www.newpig.com.au)

**Matthews**  
SAFETY PRODUCTS

1800 HOT HOG (468 464)